

# Nu-Edge<sup>®</sup> SL

Cobalt Chromium Brackets



## Wire Sequence Guidelines

# 1

### ALIGNMENT

.014"

TPO<sup>®</sup> Original Reflex<sup>®</sup> Nickel Titanium Wire  
TPO Reflex Heat-Activated Nickel Titanium Wire

.016"

TPO Original Reflex Nickel Titanium Wire  
TPO Reflex Heat-Activated Nickel Titanium Wire

# 2

### LEVELING

.016" x .022"

TPO Original Reflex Nickel Titanium Wire  
TPO Reflex Heat-Activated Nickel Titanium Wire  
TPO TiMolium<sup>®</sup> Titanium Wire

.018" x .025"

TPO Original Reflex Nickel Titanium Wire  
TPO Reflex Heat-Activated Nickel Titanium Wire

.017" x .025"

TPO TiMolium Titanium Wire

# 3

### WORKING PHASE

.016" x .022"

TPO Shiny Bright Stainless Steel Wire

.018" x .025"

TPO Shiny Bright Stainless Steel Wire

# 4

### DETAILING FINISHING PHASE

.016" x .022"

TPO Shiny Bright Stainless Steel Wire

.018" x .025"

TPO Shiny Bright Stainless Steel Wire

### FULL ENGAGEMENT OF SLOT

.017" x .025"

TPO Shiny Bright Stainless Steel Wire

.0215" x .025"

TPO Shiny Bright Stainless Steel Wire

Find out more at [tportho.com](http://tportho.com)  
or call **800-348-8856**

